

## **Important informations**

Please take the time to carefully read through the whole of these instructions before you commence.

Keep these instructions for future reference.

Unpack, inspect and check aof all of the contents.

Please dispose of all packing safely.

Small components parts could choke a child if swallowed.

We strongly recommend that you keep children well away from the work area.

It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid scratching this product and protect your floor.

This product is heavy. Take extreme care when lifting to avoid personal injury or damage to the product.

This bed is heavy. Always lift the bed with to people.

Assemble the product as close to its intended final position in the room as possible.

Keep any sharp object away from the bed frame.

**HANDY HINT:** If you keep the hardware in a bowl during assembly you will be less likely to lose them.

### **HEALTH & SAFETY**

**DO NOT:** jump on this bed frame.

**DO NOT:** use this bed frame if any parts are missing, damaged or worn.

**DO NOT:** use this bed frame unless all fixings are secured.

**DO NOT:** push the bed frame as this will damage the legs.

Always lift the bed frame with two people to reposition.

Always use on a level, even surface.

Following installation of the mechanism lift / pull the base up and down a few times to free of the system-the gas cylinders fitted to the system may be stiff when first time used or if the system has not been operated for a period of time. The mattress must be fitted to the base.

Use the strap handle to lift up the mattress base using tow hands-Pull the mattress base down using two hand equally spaced from the mattress.

**WARNING:** If this bed is placed on a non-carpeted floor you must place some protection under all legs to stop the bed frame from moving. If this is not adhered to there is no guarantee if the bed frame collapses.

**WARNING:** This storage bed frame has a powerful, mechanism and after assembly should only be opened when mattress is in place.

### **CAUTION**

**DO NOT:** allow children to operate the mechanism.



















**DO NOT:** allow children near the lift base when operating the mechanism.

**DO NOT:** allow children in the area of the internal storage base.





















Keep hands clear of the mechanism when operating the system.

**DO NOT:** stand inside the bed / on the internal storage base.

**DO NOT:** overload the internal storage.

PART LIST			
PART	DESCRIPTION		
		QTY	BOX
1	Headboard Frame		1
2	Left Wooden Post		1
3	Right Wooden Post		1
4	Footboard		1
5	Side Rail - Left & Right		2
6	Back Storage Panel		1
7	Base Panel		4
8	Center Storage Panel		1
9	Left Hydraulic Base Support		1
10	Right Hydraulic Base Support		1
11	Hydraulic Pump		2
12	Back Side Bar		1
13	Front Side Bar		1
14	End Bar Left		1
15	End Bar Right		1
16	Center Bar		1
17	Middle Bar		2
18	Wood Slat		14


### HARDWARE LIST (Found in box 3)

PART	DESCRIPTION		QTY	BOX
A	Mini Fix		8	3/3
B	M8 x 30mm Wood Dowel		12	
C	ML-CB (Metal Corner Support)		2	
D	M6 x 90mm JCBC Bolt RBW + Barrel Nut		4	
E	M8 x 25mm JCBC Bolt RBW		16	
F	M8 x 15mm JCBC Bolt RBW		8	
G	M6 x 30mm JCBC Bolt BLK		4	
H	M6 x 45mm JCBC Bolt BLK		8	
I	Flat Bracket		4	
J	Base Handle		3	
K	M8 x 20mm JBCB Bolt RBW		8	
L	M6 x 40mm JCBC Bolt BLK		8	
M	M8 x 45mm JCBB Bolt RBW c/w Nut Bracket, Spring Washer & Flat Washer		6	
N	Single End Plastic Cap		28	
O	Self adhesive 4mm x 35mm		2	
P	Wood Button		4	
Q	M6 Allen Key		1	
R	M8 Allen Key		1	
S	M12.8 Spanner		1	
T	Washer Bracket		4	

\*\* You will also need a screw driver and small mallet (not provided).

**Step 1:** Attach the headboard frame (1) and back storage panel (6) to the left wooden post (2) and right wooden post (3). Secure the headboard frame using hardware parts **B**, **D** and **P**, then secure the back storage panel with hardware parts **B** and **A**.


DO NOT use any power tools as this may damage the frame and will invalidate any claim.




FRONT VIEW

**Step 2:** Join together the left side rail and right side rail (7) with the centre storage panels (8) using hardware parts A and B.



DO NOT use any power tools as this may damage the frame and will invalidate any claim.



**Step 3:** Attach the headboard frame (1) and footboard (4) to the side rails using hardware part E.  
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




**Step 4:** Insert the base panel (7) to the position.




Do Not Use Power Tools

**Step 5:** Firstly, fix the hydraulic pump to each hydraulic base support as shown in diagram 5.1






Next ensure your hydraulic opening side, locate your hydraulic base support through the JCBC holes L1, L2, L3 & L4 or R1, R2, R3 & R4 at the headboard and footboard as shown in diagram 5.2.




**OPTION 1 (LEFT OPENING)**



**OPTION 2 (RIGHT OPENING)**




Make sure to fix bolts K at round end hole first (L1/R1) as shown in diagram 5.3 and do not tighten yet. Finally, fix all bolts and tighten all bolts as shown in diagram 5.4.





Do Not Use Power Tools



**Step 6:** Attach hardware part C using hardware parts F.  
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




**Step 7:** Join together the front, back bed base (12)(13) and end bar left, right (14)(15) using hardware parts H, I and T. Attach parts (16) and (17) using hardware part G & L.  
DO NOT use any power tools as this may damage the frame and will invalidate any claim.




Do Not Use Power Tools

**Step 8:** Fit the slat cap N onto the spring slat (18) and insert into the pre-drilled holes. Please note you may need to press firmly into place. After that fix base handle J to the bed base with bolts L as shown.




**Step 9:** Assemble the bed base on the left & right hydraulic frame and fix bolts starting from '1' to '3' as shown and then stick it the self adhesive O as shown.

DO NOT use any power tools as this may damage the frame and will invalidate any claim.







**Step 10:** Adjust the bed base, make sure that the distance with the side rail approximately 15mm to above. Tighten all bolts and screws.




**THE BED HAS BEEN FULLY ASSEMBLED**

Option 1 (LEFT OPENING)



Option 2 (RIGHT OPENING)




## IMPORTANT NOTE

WHEN THE BED IS BUILT AND THE MATTRESS FRAME IS AT 45 DEGREE ANGLE PLEASE PLACE THE MATTRESS ON THE BED.

PLEASE NOTE THAT THE WEIGHT OF THE MATTRESS IS REQUIRED TO HELP CLOSE THE BED.

TO LOWER THE SLEEPING PLATFORM STAND AT THE FOOT END OF THE BED AND PUSH SHARPLY DOWNWARDS USING BOTH HANDS.



**WARNING:** Take care when assembling the base. Assemble the ottoman as closed to its final position. The Ottoman has a powerful, mechanism and after assembly should only be opened when the mattress is in place.